RIMAGE MEDICAL DISC DEVICE™ 2410

A Powerful In-House Solution For Your DICOM CD/DVD Production

The Rimage MDD 2410 system is a high-performance, front-office solution for automated Patient CD/DVD Production. Your Medical Imaging workflow will benefit from a fully automated and intelligent in-house robotic solution with a low long-term cost of ownership.

Benefits

Affordable

The Rimage MDD 2410 is the most affordable disc publishing system with a thermal printer. It is the easiest way to get Rimage quality publishing in an affordable package. All you need is a PC, the solution software and you are ready to go.

Network connectivity

The MDD 2410 system can be easily networked using an external PC.

Integrated printer

Rimage's Everest® 400 printer is the market's only fully integrated thermal retransfer printer, providing indelible, high-resolution images and sharp, easy-to-read text. Unlike inkjet printing, thermal reftransfer printed labels will not scratch, smear, peel or fade over time.

Unmatched performance

The three-bin carousel with optional 50-disc output bin enables multiple patient discs and media types to run concurrently. Publish up to 50 CD-Rs, DVD-Rs, or Blu-ray Discs[™] per hour with hands-free operation.

Features

Backed by Rimage's decades of experience in designing and building hardware, the MDD 2410 standard features include:

- Integrated DiscWatch™ status light
- Two quick-release front-swappable recorders
- LCD status display
- Rotating three-bin 150-disc carousel for input/output
- External five-disc output bin
- Integrated Everest 400 thermal retransfer printer
- Internal lighting
- USB 3.0 connectivity



Options

- Blu-ray recorders
- 50-disc external output bin



RIMAGE[®]

SYSTEM SPECIFICATIONS

	MEDICAL DISC DEVICE 2410
CPU/RAM/HDD	User Supplied
Number of Recorders	2 CD/DVD (optional BD)
Carousel / Total Capacity	3 bins / 150 discs
External Output Bin Capacity	5 discs (optional 50-disc external output bin)
Printer	Everest 400
USB Port	USB 3.0
Print Speed	60 seconds
Print Ribbons	CMY and Black
Rimage Software Suite (RSS)	A set of software tools enabling unique artwork design, job submission, control center operation, production monitoring and custom application creation. Included in the Rimage Software Suite are CD Designer™, QuickDisc™, WebRSM™, WebQD™ and Rimage System Manager.
Height	19 in / 48,3 cm
Width	14,8 in / 37,6 cm
Depth*	19,5 in / 49,5 cm
Weight	64 lb / 29 kg
Power Specifications	100 – 240VAC, 60/50 Hz, 3,4 - 2,4A, 500W max
Warranty	12 months

* Allow space (3,5" or 9 cm) in rear of machine for cabling.

We Recommend

Rimage Maintenance Agreements

Maximize your ROI and minimize downtime when quick problem resolution is a must. With our range of skilled technicians and industry-leading support services, Rimage has a maintenance plan that meets your needs.

Rimage Media Kits

The MDD 2410 is designed for use with Rimage MDD Media Kits. MDD Media Kits contain optimized ribbons and matched sets of CD, DVD or Blu-ray Discs to ensure you produce the best-looking, longest-lasting results in one convenient and affordable package.

For complete information about Rimage Medical Disc Device support options and Media Kits, visit www.rimage.com.

Blu-ray Disc™ is a trademark of the Blu-ray Disc Association.



