RIMAGE PROFESSIONAL™ 5410N

A Powerful In-house Solution Delivering Quality Results

The Rimage Professional 5410N is a high-performance, front-office solution for automatically creating CDs, DVDs and Blu-ray Discs™ with customized digital content and direct-to-disc printing. Your business will benefit from a fully automated and intelligent in-house digital publishing solution with a low long-term cost of ownership.

Benefits

Integrated embedded computer

The 5410N has a full-featured Windows 7 Ultimate 64 bit computer with an Intel® Core™ 4th Generation i3 processor and 4GB of RAM enabling networking, running local applications and maximizing throughput.

Small footprint

The 5410N system is designed to tuck into tight spaces. With an embedded PC and fewer cables/connections, the 5410N provides increased data throughput, faster disc production and a reduced overall footprint, when compared to a Rimage 3410.

Network connectivity

With two Intel Gigabit Ethernet connections, the networked 5410N system is as simple to use as a printer or copier.

Integrated printer

Rimage's Everest® 400 printer is the market's only fully integrated 400 dpi thermal printer, providing indelible, high-resolution images and sharp, easy-to-read text.

Unmatched performance

The three-bin carousel with optional 50-disc output bin enables up to three media types concurrently, or load all the bins with the same media type for longer operation without needing to load discs. Publish up to 18 full DVD-Rs (4.7 GB) and 30 full CD-Rs (700 MB) per hour with hands-free operation.



Professional 5410N shown with optional 50-disc external output bin

Options

- Blu-ray recorders
- 50-disc external output bin
- Media Reader

Features

Backed by Rimage's decades of experience in designing and building hardware, the Rimage 5410N standard features include:

- Integrated DiscWatch™ status light
- Front USB 2.0 and rear USB 3.0 ports
- Two quick-release recorders
- LCD status display
- Embedded Windows Ultimate 7 64 bit computer Rotating three-bin 150-disc carousel for input/output
 - External five-disc output bin (50 disc output optional)
 - Integrated Everest 400 thermal retransfer printer
 - Internal lighting

SYSTEM SPECIFICATIONS	
PROFESSIONAL 5410N	
CPU	Intel 4th Generation i3-4330
RAM	4 GB
HDD Storage	3 x 500 GB, Two RAID 0 volumes
Operating System	Win 7 Ultimate 64-bit
Number of Recorders	2 CD/DVD (optional BD)
Carousel / Total Capacity	3 bins / 150 discs
External Output Bin Capacity	5 discs (optional 50-disc external output bin)
Printer	Everest 400
Print Speed	60 seconds
Print Ribbons	CMY, Black
Rimage Software Suite	Included in the Rimage Software Suite are CD Designer™, QuickDisc™, WebRSM™, WebQD™ and Rimage System Manager.
Height	19 in / 48.3 cm
Width	14.8 in / 37.6 cm
Depth*	19.5 in / 49.5 cm
Weight	69 lb / 31 kg
Power Specifications	100 - 240VAC, 60/50 Hz, 3.9 - 2.6A, 500W max
Warranty	12 months

^{*} Allow space (3.5" or 9 cm) in rear of machine for cabling.

We Recommend

Rimage Maintenance Agreements

Maximize your ROI and minimize downtime when quick problem resolution is a must. With our range of skilled technicians and industry-leading support services, Rimage has a maintenance plan that meets your needs.

Rimage Media Kits

Get reliable, uninterrupted performance from your Professional system. With optimized print ribbons and discs, Media Kits give you the best-looking, longest-lasting results in one convenient and affordable package.

For complete information about Rimage Professional Series support options and Media Kits, visit www.rimage.com. Blu-ray Disc[™] is a trademark of the Blu-ray Disc Association.