

RIMAGE PRODUCER™ V DISC PUBLISHING SYSTEM



Robust and Reliable, Engineered for Performance

The next generation Producer V is the most powerful disc publishing system from Rimage, engineered for 24x7 performance. With industrial-grade robotics, direct-to-disc printing and professional recording technologies, Producer V meets the world's most challenging disc publishing demands for CD, DVD and Blu-ray Discs™. Advanced features such as SSD startup and HDD cache combine with powerful enhancements including filtered positive airflow and front removable hard drives to bring you unrivaled performance and quality.

Powerful printing

Producer V systems have the world's best full-colour and monochrome thermal disc printers, providing top of the line printing and industrial-grade production in one scalable package.

Quick turnaround

Designed for 24/7, high-volume and unattended production, Producer V systems publish hundreds of customisable discs per day, so you can deliver customer-tailored discs faster.

Superior performance

A four-bin carousel and 100-disc external output bin are standard with the Producer V system, enabling four media types to be available concurrently. The reliable Rimage robotics are designed to output discs continuously for years, and filtered positive airflow improves system operation and efficiency.



Features

- Four quick-release front-swappable recorders
- Filtered positive airflow for optimal performance in all conditions
- Front removable hard drives
- Operating system on SSD for fast startup with 16 GB of RAM
- 400-disc rotating carousel for input/output
- 100-disc external output bin
- Integrated DiscWatch™ status light
- Four line LCD status display
- Front accessible USB 3.0 port
- Rear USB 2.0 and 3.0 ports
- Embedded computer with network connectivity (8300N only)
- Rimage Software Suite (RSS)
- Your choice of Everest Encore or Prism III print technology

Recorder Option

- Blu-ray Disc recorders

Select your printer

Everest® Encore™

Permanent, vibrant colour with thermal retransfer printing. Removable retransfer and print ribbon carriages for convenience.

Prism III™

Fast and cost-effective direct thermal monochrome printing. Available perfect print technology provides registered printing on silk-screened media.



SYSTEM SPECIFICATIONS

8300N		8300
Number of Recorders	4	
Carousel/Total Capacity	4 bins/400 discs	
External Output Bin Capacity	100 discs	
Printer	Everest Encore or Prism III	
CPU	Intel Core i5-7500	User supplied
Trusted Platform Module (TPM)	Included	N/A
HDD Storage	1 x 256 GB SSD (OS) 3 x 500 GB HDD (Cache)	User supplied
RAM	16 GB	
Operating System	Win 10 Enterprise 64-bit	
Network Adapters	Two 1 GB Ethernet	
Rimage Software Suite (RSS)	A full set of software tools enabling unique artwork design, job submission, control center operation, production monitoring and custom application creation.	
CD Designer™	Label creation software – included	
QuickDisc™	Disc burning software – included	
Rimage System Manager (RSM)	Control and manage the system, locally or through your network – included	
Filtered Positive Airflow	Yes	
Height	31.5 in/80 cm	
Width	16.75 in/42.5 cm	
Depth*	23.5 in/59.7 cm	
Weight (without printer)	92.7 lb/42.0 kg	89.0 lb/40.3 kg
Weight w/ Everest Encore	136.7 lb/62.0 kg	133.0 lb/60.3 kg
Weight w/ Prism III	112.7 lb/51.1 kg	109.0 lb/49.4 kg
Power Specifications	100 - 240 VAC, 60/50 Hz, 3.9 - 2.6 A, 500 W max.	
Warranty	12 months	

* Allow space (3.5" or 9 cm) in rear of machine for cabling.

We Recommend

Rimage Maintenance Agreements

Maximize your ROI and minimise downtime when quick problem resolution is a must. We will be of assistance in determining the right service option for you.

Rimage Media Kits

Get reliable, uninterrupted performance from your Producer V system. With optimised print ribbons and discs, the Rimage Media Kits give you outstanding, long-lasting and highly consistent printing results in one convenient and affordable package.

For more information about the Rimage Producer V series service options and media kits, visit rimage-emea.eu.



Rimage EMEA GmbH
Mainzer Strasse 131
65187 Wiesbaden
Germany
+49 611 927770
sales@rimage.eu
rimage-emea.eu

