

RIMAGE PRINTER TECHNOLOGY

Superior Print Technology, Superior Results

From the industry's fastest and most economical thermal retransfer print quality to the most durable, high-resolution printed surface, Rimage AutoPrinter, Everest® Encore™ and Prism III™ disc printing systems meet the daily demands of continuous, high-capacity digital publishing.

AutoEverest™ Encore and AutoPrism™ III AutoPrinters

Automated direct-to-disc printing on these printers allow you to simply load your discs and walk away.

Features

- Robust robotics for automatic disc printing
- Small footprint for desktop use
- Choose between Everest Encore color and Prism III monochrome printers
- Three 100-disc input bins enable efficient production of jobs from 1 to 300 discs without user intervention
- No additional set-up, clean-up time, cost or specialized operators required



AutoPrism III

Everest Encore Standalone Printer

Thermal retransfer print technology delivers durable CD/DVD/ Blu-ray Disc™ labeling, with the highest print resolution in the industry.

Features

- Permanent printing ensures discs are scratch proof, waterproof, fade resistant and UV protected
- 600 dpi resolution delivers photo quality images
- Edge-to-edge printing fully utilizes the media surface
- Intelligent system keeps track of the remaining print ribbons and communicates the information throughout the printing process
- Removable retransfer and print ribbon cartridges for convenience



Everest Encore
Standalone Printer

Prism III Standalone Printer

A high-speed printer for monochrome printing on CD/DVD/Blu-ray Discs.

Features

- Print an entire disc in four seconds for less than four cents per disc
- PerfectPrint technology provides registered printing on original, silk-screened media
- Ribbon Saver reduces ribbon waste by only using the amount needed, lowering costs and maximizing throughput
- Print head integrity check automatically tests the print head elements, ensuring high quality images
- Cleaning mode allows you to clean the print head surface quickly and easily



Prism III Standalone Printer

SYSTEM SPECIFICATIONS

	EVEREST ENCORE		PRISM III	
	STANDALONE	AUTOPRINTER	STANDALONE	AUTOPRINTER
Print Technology	Thermal Retransfer		Direct Thermal	
Print Resolution	600 dpi		300 x 300 dpi or 300 x 600 dpi	
Print Speed	60 seconds		< 5 seconds per disc	
Print Ribbons	CMY, Black		Black, Blue, or Red Monochrome CMY Spot Color	
CD Designer Software	Included			
Interface	USB 2.0 High Speed			
Height	9.7 in / 24.6 cm	22.3 in / 56.6 cm	6.3 in / 16 cm	22.3 in / 56.6 cm
Width	9.5 in / 24.1 cm	14.75 in / 37.5 cm	8.5 in / 21.6 cm	14.75 in / 37.5 cm
Depth*	14.8 in / 37.6 cm	21.25 in / 54 cm	14 in / 35.6 cm	21.25 in / 54 cm
Weight	44 lb / 20.0 kg	101 lb / 45.8 kg	20 lb / 9.1 kg	77 lb / 34.9 kg
Power Specifications	100 - 120 Vac, or 220 - 240 Vac, 500W, 60-50 Hz, 3.7 - 3.9/2.9 - 3.1 Amp, manual switching		100 - 240 Vac, 120W, 60-50Hz, 1.1 - 0.45 Amp	
Warranty	12 months			

* Allow space (3.5" or 9 cm) in rear of machine for cabling.

We Recommend

Rimage Maintenance Agreements

Maximize your ROI and minimize downtime when quick problem resolution is a must. With our range of skilled technicians and industry-leading support services, Rimage has a maintenance plan that meets your needs.

Rimage Media Kits

Get reliable, uninterrupted performance from your printer. With optimized print ribbons and discs, Media Kits give you the best-looking, longest-lasting results in one convenient and affordable package.

For complete information about Rimage Printer Series support options and Media Kits, visit www.rimage.com.

Blu-ray Disc™ is a trademark of the Blu-ray Disc Association.

