

# RIMAGE PRODUCER™ V+ DISC PUBLISHING SYSTEM

## Robust and Reliable, Engineered for Performance

The next generation Producer V+ is the most powerful disc publishing system from Rimage, engineered for 24x7 performance. With industrial-grade robotics, direct-to-disc printing and professional recording technologies, Producer V+ meets the world's most challenging disc publishing demands for CD, DVD and Blu-ray Discs™. Advanced features such as NVME-SSD startup and SSD cache combined with powerful enhancements including filtered positive airflow and front removable cache drive to bring you unrivaled performance and quality.

### Powerful printing

Producer V+ systems have the world's best full-colour and monochrome thermal disc printers, providing top of the line printing and industrial-grade production in one scalable package.

### Quick turnaround

Designed for 24/7, high-volume and unattended production, Producer V+ systems publish hundreds of customisable discs per day, so you can deliver customer-tailored discs faster.

### Superior performance

A four-bin carousel and 100-disc external output bin are standard with the Producer V+ system, enabling four media types to be available concurrently. The reliable Rimage robotics are designed to output discs continuously for years, and filtered positive airflow improves system operation and efficiency.

## Features

- Four quick-release front-swappable recorders
- Filtered positive airflow for optimal performance in all conditions
- Front removable cache drive
- Operating system on NVME-SSD for fast startup with 16 GB of RAM
- 400-disc rotating carousel for input/output
- 100-disc external output bin
- Integrated DiscWatch™ status light
- Four line LCD status display
- Front accessible USB 3.0 port
- Rear USB 2.0 and 3.0 ports
- Embedded computer with network connectivity (8300N+ only)
- Rimage Software Suite (RSS)
- Your choice of Everest Encore or Prism III print technology



### Recorder Option

- Blu-ray Disc recorders

### Select your printer

#### Everest® Encore™

Permanent, vibrant colour with thermal retransfer printing. Removable retransfer and print ribbon carriages for convenience.

#### Prism III™

Fast and cost-effective direct thermal monochrome printing. Available perfect print technology provides registered printing on silk-screened media.



## SYSTEM SPECIFICATIONS

	8300N+	8300
Number of Recorders	4	
Carousel/Total Capacity	4 bins/400 discs	
External Output Bin Capacity	100 discs	
Printer	Everest Encore or Prism III	
CPU	Intel Core i5-10500E	User supplied
Trusted Platform Module (TPM)	Included	N/A
HDD Storage	System drive: 1 x 500 GB NVME Cache drive: 1 x 1 TB SSD	User supplied
RAM	16 GB	
Operating System	Win 11 IoT Enterprise	
Network Adapters	Two 1 GB Ethernet	
Rimage Software Suite (RSS)	A full set of software tools enabling unique artwork design, job submission, control center operation, production monitoring and custom application creation.	
CD Designer™	Label creation software – included	
QuickDisc™	Disc burning software – included	
Rimage System Manager (RSM)	Control and manage the system, locally or through your network – included	
Filtered Positive Airflow	Yes	
Height x Width x Depth*	80 cm x 42.5 cm x 59.7 cm 31.5" x 16.75" x 23.5"	
Weight (without printer)	42.0 kg/92.7 lb	40.3 kg/89.0 lb
Weight w/ Everest Encore	62.0 kg/136.7 lb	60.3 kg/133.0 lb
Weight w/ Prism III	51.1 kg/112.7 lb	49.4 kg/109.0 lb
Power Specifications	100 - 240 VAC, 60/50 Hz, 3.9 - 2.6 A, 500 W max.	
Environmental Temperature Requirement	Operating: 16 °C to 30 °C (60 °F to 86 °F) Storage: -15 °C to 35 °C (5 °F to 95 °F)	
Environmental Humidity Requirement	40% to 80% non-condensing	
Warranty	12 months	

\* Allow space (9 cm or 3.5") in rear of machine for cabling.

## We Recommend

### Rimage Maintenance Agreements

Maximize your ROI and minimize downtime when quick problem resolution is a must. We will be of assistance in determining the right service option for you.

### Rimage Media Kits

Get reliable, uninterrupted performance from your Producer V+ system. With optimized print ribbons and discs, the Rimage Media Kits give you outstanding, long-lasting and highly consistent printing results in one convenient and affordable package.

For more information about the Rimage Producer V+ series service options and media kits, visit [rimage-emea.eu](http://rimage-emea.eu).



**Rimage EMEA GmbH**  
Mainzer Str. 131  
65187 Wiesbaden  
Germany  
+49 611 927770  
[sales@rimage.eu](mailto:sales@rimage.eu)  
[rimage-emea.eu](http://rimage-emea.eu)

